

Phone: 1-989-671-9721 FAX: 1-989-671-2941 www.winford.com

# Surface Mounting BRKEx8PB-N & BRKEx10PB-N Mount Your RJ45/RJ50 Breakout Board with Enclosure

Although part numbers BRKEA8PB-N, BRKEG8PB-N, BRKEA10PB-N, and BRKEG10PB-N are primarily intended for cable end termination, they also come with accommodations for mounting the enclosure to a surface using the simple steps below:

### 1. Remove PCB from enclosure

- Remove screws and enclosure top
- Remove snap rivets



Figure 1.1

- Push down on the center post of each snap rivet; freeing it from the enclosure base (Figure 1.1)
- Remove PCB

## 2. Drill out preformed divots

1/8" through-hole recommended (Figure 1.2)



Figure 1.2

## 3. Mount enclosure base

 Install mounting hardware (#4 flat-head screws recommended) through divots, securing the enclosure base to the mounting surface. (Figure 1.3)



Figure 1.3

### 4. Reinstall PCB

• Place PCB in proper orientation



 Install snap rivets "backwards" (i.e. through the top of the PCB) (Figure 1.4)

Figure 1.4

• Install terminating wires, enclosure top, and screws, and you're done! (Figure 1.5)



Figure 1.5

Please contact us if you're interested in purchasing unassembled enclosure parts or kits.